

Setting up a Strong SRT4653x/SRT4663x to receive the SelecTV Channels on Intelsat8

This guide assumes the decoder has been purchased new and has never been setup before. If it has been setup before, you may wish to reset the decoder to FACTORY DEFAULT. You will find this under MENU ~ SYSTEM SETTINGS ~ DATABASE RESET.

Switch the unit on at the rear and you will be presented with the menu language choice...

Press OK to select ENGLISH.

Press MENU

Press OK on INSTALLATION

Enter 0000

Press OK on DISH SETTING

Change the satellite name to PAS8/KU or INTELSAT8/KU using the right arrow key

Move down to LNB TYPE and change to SINGLE

Move down to LNB FREQ and press OK

Choose either 10.700 or 11.300 depending on the LNB you have (read the label on the LNB if unsure) then press OK to select it from the list.

Press EXIT

You will be asked if you wish to save

Move to YES and press OK

Move down to MANUAL SCAN

Press OK

Ensure the SATELLITE NAME is PAS8/KU or INTELSAT8/KU

Move to FREQ

Scroll through the list with the right arrow and find 12.286 (if it is not in the list press 1 and it will prompt if you wish to ADD, press OK and type in 12286, move down to symbol rate and type in 28800, move to POLARIZATION and change to HOR)

If you do not have green LEVEL and QUALITY at this stage you have either chosen the wrong LNB FREQ, your cables are not connected correctly, your dish is not aligned OR your LNB is faulty.

If green, move down to NETWORK SEARCH

Press OK

Wait until the scan is finished – you will be returned to the MANUAL SCAN screen.

Press EXIT three times.

Done..

Press OK to bring up the channels.

Move to one of the SelecTV channels and press OK

If the channel is scrambled you may have to activate your smartcard.